

# PXA Installation instructions

The new PXA enclosure from Autometers containing the IC-5 meter making a meter installation even easier.

**WARNING** - The PXA enclosure fitted with the IC-5 meter inside should only be installed by a competent and qualified electrician who is fully aware of the latest electricity regulations concerning the installation of Electricity meters. The AD3-80M and the AD3-5M must be installed in a suitable enclosure.



**1.** Remove the two countersunk screws which are fitted at the top and bottom of the case.



**2.** You will notice two small indents at the top right and left hand side of the case, insert your fingers at this point and gently prise apart.

This should release the cover from the base.



**3.** Now repeat step 2 above but this time at the bottom of the case.



**4.** Pulling gently out slide the cover forward and of the base.



**5.** Looking inside the base you will notice 2 x 20mm knock outs at the top and at the bottom.

To remove these place a screw driver inside the case and tap out the knock out.



**6.** Remove the three plastic plugs to reveal the fixing points of the base.



**7.** Hold against the wall and mark the fixings.



**8.** After you have secured the base to the wall, re-fix the three plastic covers over the fixing screws.

Remove the terminal cover of the meter and connect your cables.



**9.** Holding the cover in your hands as per the picture, slide the cover on. You should feel a slight click as the cover fits on the base.

Tap the four corners so they are all in position.



**10.** Secure the two fixing screws top and bottom.