

ADM-F Modbus Connection Diagram

TERMINAL: 1 - Neutral
3 - Live

5 - RT- (Resistor 120 ohm)
6 - RT+ (Resistor)
7 - Earth Shield
8 - D- (RX-)
9 - D+ (RX+)

FRONT PANEL

A green LED reports the state of the communication with the meter.

- LED Blinking: Communication not active
- LED On: Communication active.

DEFAULT SETTINGS:

Baud Rate: 9,600 BIT/S
Protocol: Autometers V6
Address: 001
Parity: Even
Stop Bits: 1

Do NOT press the Reset Button with out contacting Autometers.

